

FTM-300DR/DE

DSP Firmware

Update Instruction Manual

Introduction

This application is a software tool for updating the firmware of transceivers manufactured by Yaesu Musen Co., Ltd.

CAUTION!

*Be sure to confirm the model and the version of your transceiver before starting the update.
Writing incorrect firmware to the transceiver may cause abnormal operation or failure.*

Important Notes

- All responsibility for the use of this software lies with the customer. Yaesu cannot be held responsible in any way for any damages or losses, which may be incurred by the customer as a result of using this software.
- Copyrights and all other intellectual property rights for the software, as well as the software manual, are the property of YAESU MUSEN CO., LTD.
- Revision, modification, reverse engineering, and decompiling of this software is prohibited. Redistribution, transfer, and resale of downloaded files are also prohibited.
- Downloaded files may only be used for personal use.
- If you cannot perform the firmware upgrade yourself, please consult with one of our sales sites or service centers.

Trademarks

Microsoft®, Windows®, Windows® 8.1, and Windows® 10 are registered trademarks in the United States and other countries.

System Requirements (Operating Environment)

To use this program, a personal computer (PC) with one of the following Windows operating systems, and a USB data connection cable are required

Supported Operating Systems

One of the following operating system environments:

- Microsoft® Windows® 10 (32 bit / 64 bit)
- Microsoft® Windows® 8.1 (32 bit / 64 bit)

CPU

The performance of the CPU must satisfy the operating system requirements.

RAM (System Memory)

The capacity of the RAM (system memory) must be more than sufficient to satisfy the operating system requirements.

HDD (Hard Disk Drive)

The capacity of the HDD must be more than sufficient to satisfy the operating system requirements.

In addition to the memory space required to run the operating system, about 50 MB or more of additional memory space is required to run the program.

USB interface

USB interface (USB Port)

Cable

Supplied USB cable

Install / Uninstall Procedure

Installation procedure

Download the “FTM-300DR/DE DSP Firmware Update Program”; with this software, you can update the FTM-300DR/DE DSP firmware.

1. Download the update program from the Yaesu web site.
2. Extract the downloaded zip file, and save the data contained inside the zip file to any desired location.

Uninstall procedure

1. Delete the folder opened by the update program.

The operation will end if the opened folder is deleted since no data will be written to the registry and system folder.

Overview of Firmware Update

Update the firmware by following the procedures below:

“Installing a USB Device Driver” (P. 3)



“Updating the DSP Firmware” (P. 5)

Displaying the Firmware Version

To display the transceiver firmware version:


1. Press and hold the **[F(SETUP)]** key.
2. Rotate the **DIAL** knob to select Set-up menu **[DISPLAY]**, then press the **DIAL** knob.
3. Rotate the **DIAL** knob to select **[5 SOFTWARE VERSION]**, then press the **DIAL** knob.
4. The software versions of “**Main**”, “**Sub**” and “**DSP**” are shown.

Main Ver. : X.X
Sub Ver. : X.X
DSP Ver. : X.XX

Installing a USB Device Driver


Before updating the FTM-300DR/DE DSP firmware, install the device driver.

- * The following procedure must be performed only when using the software for the first time. When the device driver is already installed on your computer, skip the following procedure.
 - * The procedure to install the driver on a Windows 10 computer is shown below for the purpose of explanation.
1. Open the folder in which you saved the files in step 2 of “**Installation procedure**” (P. 2).
 2. Right-click the “**FTM-300D_Com.inf**” file, and then select **[Install]** from the menu displayed.




The “**User Account Control**” screen appears.

3. Click the **[Yes]** button.




The “**Windows Security**” screen appears.

4. Click the **[Install]** button.



The device driver installation begins. When the installation completes, the message "The operation completed successfully." appears.

5. Click the **[OK]** button.



Updating the DSP Firmware

Execute the FTM-300DR/DE DSP firmware update.


- * Do not connect the FTM-300D to your PC until step 5 below. If it is already connected, disconnect the USB cable, and start over from step 1 below.

1. Double-click “**PCTOOLe_vxxxx.exe**” (D icon).


* “XXX” refers to the version number.




The following screen will be displayed.




2. When the power of FTM-300DR/DE is **ON**, press and hold the [**POWER**] switch to turn it **OFF**.
3. Press and hold the [**D X**] key and the [**F(SETUP)**] key on the FTM-300DR/DE while turning the power **ON**.
“**DSP UPDATE**” is displayed on the FTM-300D screen.



4. When “**PUSH D KEY**” is displayed, press the [**D X**] key.
“**DSP ↔ COM**” is displayed on the FTM-300D screen.




5. Use the supplied cable to connect the FTM-300DR/DE DATA jack to the computer.




6. Check that “**YAESU FTM-300D communication device (COMXX)**” appears under “**Ports (COM & LPT)**” and then close “Device Manager”.


* “XX” refers to a port number. Since “**COMXX**” will be required when updating the DSP firmware, write down the port number.



7. From the **[COM Port]** drop-down list, select the COM port, which you found listed in the “**Device Manager**” when you installed the device driver, and then click the **[OK]** button.




8. Click the **[Update]** button on the “YAESU Amateur Digital DSP Firmware Update Program” screen.




A confirmation message appears.

9. Read the message to check the version and then click the **[OK]** button.




The DSP firmware transfer will begin, and the FTM-300DR/DE DSP firmware update executes. When the DSP firmware update completes, a message appears.

10. In the confirmation dialog box displayed on the computer screen, click the **[OK]** button.




The DSP firmware post-update procedure appears.

11. Press and hold the **[POWER]** key to turn the power **OFF**.
12. Disconnect the USB cable from the transceiver.
13. Click the **[OK]** button.



14. Press and hold the **[POWER]** key to turn the power **ON**.
15. Check the firmware version. Press and hold the **[F(SETUP)]** key.
16. Rotate the **DIAL** knob to select Set-up menu **[DISPLAY]**, then press the **DIAL** knob.
17. Rotate the **DIAL** knob to select **[5 SOFTWARE VERSION]**, then press the **DIAL** knob.
18. The software versions of "Main", "Sub" and "DSP" are shown.
Main Ver. : X.X
Sub Ver. : X.X
DSP Ver. : X.XX
19. Check the firmware version and click the **[Exit]** button on the "YAESU Amateur Digital DSP Firmware Update Program" screen.



The YAESU Amateur Digital DSP Firmware Update Program finishes.



Copyright 2020
YAESU MUSEN CO., LTD.
All rights reserved.

No portion of this manual may be
reproduced without the permission of
YAESU MUSEN CO., LTD.

YAESU MUSEN CO., LTD.

Tennozu Parkside Building
2-5-8 Higashi-Shinagawa, Shinagawa-ku, Tokyo 140-0002 Japan

YAESU USA

6125 Phyllis Drive, Cypress, CA 90630, U.S.A.

YAESU UK

Unit 12, Sun Valley Business Park, Winnall Close
Winchester, Hampshire, SO23 0LB, U.K.