

Extension Instruction for MINI46

Enter extension setting by following steps.

- 1) Turn off the MINI46.
- 2) Press and hold “PTT” and “SET” buttons with switching on the MINI46 simultaneously.
- 3) - The screen for adjusting LCD Contrast would pop up as below.
 - Use ▲ and ▼ to set the LCD Contrast.




- 4) - Press “SET” button to confirm above setting and enter Power Setting screen as below.
 - Use ▲ and ▼ to enable or disable “More TX Power”. The high power will become 2W instead of 1W if “More TX Power” enables.



- 5) - Press “SET” button to confirm above setting and enter “Extend CH” as below.
 - Use ▲ and ▼ to enable or disable the extend channel function.



- 6) - Press “SET” button to confirm above setting and enter frequency setting as below.
 - Use ▲ and ▼ to select the specification you need.
 - Press “SET” button to confirm the setting.



- 7) MINI46 would reboot and save above settings.

Remark:

Please be aware that the extension setting process is not completed until MINI46 reboot. And you can stop or re-start the setting process by turning off and turning on the MINI46.